


# SIZE CHARTS



## ProFlex® Back Supports

Measure around the waist. A back support should fit snugly around the waist but not so tightly that it cannot be cinched to a comfortable closure when ready to lift.


SIZE	FITS WAISTS:
X-Small	Up to 25" (64 cm)
Small	25" to 30" (64-76cm)
Medium	30" to 34" (76-86cm)
Large	34" to 38" (86-97cm)
X-Large	38" to 42" (97-107cm)
2XLarge	42" to 46" (107-117cm)
3XLarge	46" to 52" (117-132cm)
4XLarge	52" to 58" (132-147cm)



## ProFlex® Wrist Supports

Measure around the smallest part of the wrist.

SIZE	FITS
Small	up to 6" (15 cm)
Medium	6" to 7" (15-18 cm)
Large	7" to 8" (18-20 cm)
XLarge	8" and over (20 cm)



## Ergodyne® Wrist Wraps

Measure around the wrist.

SIZE	FITS
S/M	5" to 7" (15-19 cm)
L/XL	7" to 9" (19-23 cm)


# SIZE CHARTS



## Ergodyne® Elbow Supports

In a relaxed position, measure around the widest area of the forearm just below the elbow. An elbow support should sit approximately two-to-three finger widths below the elbow crease for a comfortable fit.


SIZE	FITS
XSmall	up to 9" (23 cm)
Small	9" to 10" (23-25 cm)
Medium	10" to 11" (25-28 cm)
Large	11" to 12" (28-30 cm)
XLarge	12" to 13" (30-33 cm)
XXLarge	13" to 16" (33-36 cm)



## Ergodyne® Knee Sleeves

Measure around the center of the knee with the knee extended.

SIZE	FITS
XSmall	12" to 13" (31-33 cm)
Small	13" to 14" (33-36 cm)
Medium	14" to 15" (36-38 cm)
Large	15" to 16" (38-41 cm)
XL	16" to 18" (41-46 cm)
2X	18" to 20" (46-51 cm)



## Trex® 6300

Use shoe size to determine which size Trex® 6300 will fit your shoe or boot. Trex® 6300 should fit snugly. Trex® 6301 Replacement spikes come in one size and are sold in packs of 8.

SIZE	FITS:		
	US (mens)	EU	UK (mens)
Medium	5-8	37-41	4.5-7.5
Large	8-11	41-44.5	7.5-10.5
XLarge	11-14	44.5-48.5	10.5-13.5

# SIZE CHARTS




## ProFlex® Gloves

Measure around the palm. Do Not include the thumb area.

### SIZE:



US	EURO	FITS
Small	7	up to 8" (20 cm)
Medium	8	8" to 9" (20-23 cm)
Large	9	9" to 10" (23-25 cm)
XLarge	10	10" to 11" (25-28 cm)
XXLarge	11	11" to 12" (28-30 cm)



Use this “handy” diagram to determine which ProFlex® glove fits your hands.  
**[IMPORTANT: Make sure page is printed at 100% to keep the consistency of the chart.]**

## What size do you need?

PLACE YOUR INDEX FINGER NEXT TO THE DOTTED LINE AS SHOWN. TO GET YOUR PROPER SIZE, REFER TO THE LINE AT THE EDGE OF YOUR HAND.  
 IMPORTANT: FOR OPTIMUM GRIP AND FINGER CONTROL, GLOVE SHOULD FIT SNUG



# SIZE CHARTS



## GloWear® High Visibility Apparel

T-Shirt, Polo Shirt and Sweatshirt are individually sized S, M, L, XL, 2XL, 3XL, 4XL, 5XL and follow standard sizing.

### VEST & VEST W/SLEEVES CHEST MEASUREMENT

S/M	36-44" (91-112 cm)
L/XL	44-52" (112-132 cm)
2XL/3XL	52-58" (132-147 cm)
4XL/5XL	58-64" (147-163 cm)

### MODEL 8240HL EXPANDABLE

M/L	40-48" (102-123 cm)
XL/2XL	48-56" (123-142 cm)

### PANT SIZING (8910 & 8911) WAIST MEASUREMENT

S/M	Up to 40" (102 cm)
L/XL	Up to 46" (117 cm)
2XL/3XL	Up to 52" (132 cm)
4XL/5XL	Up to 58" (147 cm)

### PANT SIZING (8915 & 8925) WAIST MEASUREMENT

SMALL	Up to 30" (76 cm)
MEDIUM	30-34" (76-86 cm)
LARGE	34-38" (86-97 cm)
XLARGE	38-42" (97-107 cm)
2XLARGE	42-46" (107-117 cm)
3XLARGE	46-48" (117-123 cm)
4XLARGE	48-50" (123-127 cm)
5XLARGE	50-54" (127-137 cm)

### JACKET SIZING (8365, 8375, 8385) CHEST MEASUREMENT

SMALL	34-36" (86-91 cm)
MEDIUM	36-38" (91-97 cm)
LARGE	38-42" (97-107 cm)
XLARGE	42-46" (107-117 cm)
2XLARGE	46-50" (117-127 cm)
3XLARGE	50-54" (127-137 cm)
4XLARGE	54-58" (137-147 cm)
5XLARGE	58-62" (147-157 cm)

### MODEL 8935 RANGER HAT HEAD MEASUREMENT

S/M	21-22.5" (53-57 cm)
L/XL	22.5-24" (57-61 cm)

Measure circumference of head at largest point just above the ears and eyebrows

